

FIG.1



FIG.2


225
202
203
224
222
221
223
201
226
152
101
184
112
124
109
190
186
117
119
114
111
103
148
130
120
144
108
104
102
164
128
100

FIG.3


225
203
224
223
202
226
138
101
136
150
103
150
178
174
172
176
146
146
184
123
122
128
186
111
114
106
126
118
112
116
124
104
102
102
100

FIG.4


225
203
202
222
224
223
201
221
226
101
113
112
138
186
119
114
118
106
178
126
103
136
124
116
184
176
172
170
150
120
164
140
206
136
6
130
104
152
102
6
128
100

FIG.5


152
124
150
104
122
206
116
148
142
120
164
140
128
130
108
144
112
102
100

FIG.6


225
203
222
223
224
201
202
221
226
101
166
104
114
109
119
152
102
140
132
170
103
186
140
106
150
126
142
110
128
120
118
206
144
148
112
8
8
100

FIG. 7


106
140
102
100
123
138
116
162
112
138
132
188
146
110

FIG. 8


116
122
120
140
146
112
162
102
104
188
148
144
142
140
130
136
100
108

FIG.9


136
116
104
111
122
140
146
102
162
112
188
130
120
100
108

FIG.10


225
201
221
202
224
223
203
222
226
101
103
172
178
126
109
116
176
123
118
104
124
113
141
186
184
174
106
102
138
122
141
102
136
132
110
111
114
112
128
23
108
134
130
23
161
100

FIG.11


225
203
221
224
223
222
202
201
226
101
19
104
19
103
106
178
102
176
102
141
174
172
141
123
122
186
184
109
138
136
126
118
116
124
111
114
21
132
112
130
134
110
128
108
21
20
160
100
20

FIG.12


225
203
222
221
201
226
140
140
206
109
190
186
117
103
114
119
112
111
116
210
210
206
210
140
144
205
154
144
130
210
144
150
102
128
104
108
100

FIG.13


225
203
224
223
202
226
101
138
136
103
126
124
178
174
172
176
146
146
186
184
141
141
128
132
130
106
123
118
114
112
116
122
102
104
102
100

FIG.14

FIG.15


225
202
222
224
223
221
203
201
226
136
116
18
18
104
124
122
207
140
142
101
112
114
186
118
103
206
190
205
148
150
144
117
102
134
144
206
210
110
108
120
16
100
128
154
130
16


136
18
104
18
140
142
140
142
114
146
206
190
112
152
150
144
211
102
209
210
130
158
108
108
205
148
144
120
128
154
206
156
100
17
17

FIG.16


140
124
116
142
112
104
206
100
102
152
150
162
188
144
154

FIG.17


225
221
202
224
223
203
201
222
226
206
205
120
117
116
102
210
208
114
210
209
109
100
112
211
190
130
108

FIG.18


225
203
202
224
222
221
223
201
226
20
102
104
136
106
140
114
118
186
103
124
150
142
206
146
144
158
101
122
116
120
117
112
148
128
207
108
154
130
100

FIG.19


225
203
221
224
223
222
201
202
226
104
102
152
140
136
142
148
154
150
112
188
162
144
130
108
146
134
128
21
21
100

FIG.20


225
201
222
224
202
223
203
221
226


109
103
150
104
102
124
116
188
206
111
158
148
112
120
146
130
162
154
144
108
134
100

FIG.21


225
201
203
221
223
224
222
202
226
104
122
116
136
140
154
117
158
156
148
112
150
102
140
140
120
134
130
100
108
128

FIG.22


201
225
221
223
224
222
202
203
226
104
112
116
162
188
120
140
150
152
146
102
130
101
108
134
128
100

FIG.23



FIG.24



FIG.25



FIG.26



FIG.27



FIG.28



FIG.29



FIG.30



FIG.31



FIG.32



FIG.33



FIG.34



FIG.35


225
203
202
224
223
226
104
113
109
122
142
125
140
105
1460R
148
116
124
150
130
134
112
120
108
111
144
102
128
100

FIG.36


225
130
102
203
202
142
125
224
223
140
226
116
113
109
105
104
150
1460R
148
124
122
120
144
134
112
111
108
128
100

FIG.37


225
203
224
223
202
226
125
104
105
113
116
109
104
125
124
105
120
122
111
108
102
134
112
128
100

FIG.38


225
203
224
223
202
226
125
127
105
229
104
104
113
122
227
109
194
124
105
228
116
125
146 OR 148
120
111
228
196
112
164
128
108
164
218
134
220
192
229
102
130
100

FIG.39


225
203
224
223
202
226
113
109
204
204
105
116
124
125
196
120
111
194
104
192
146 OR 148
112
218
220
102
134
164
128
130
164
100

FIG.40



FIG.41


CONNECTED TO EXTENSION TABLE
CONNECTED TO BASE MODULE AND EXTENSION TABLE
CONNECTED TO MAIN FRAME
FIRST SUPPORT SYSTEM (130)
SECOND SUPPORT SYSTEM (130)
NO SUPPORT
SUPPORT WHEEL (164)
FIRST FRAME EXTENSION MEMBER (EX:TRUSS) (140)
SECOND FRAME EXTENSION MEMBER (EX:CYLINDER) (150)
THIRD FRAME EXTENSION MEMBER (EX:FIXED FRAME) (154)
FOURTH FRAME EXTENSION MEMBER (EX:MOVEABLE FRAME) (192)
NO SUPPORT 1 2 3 4 5 6
SUPPORT WHEEL (164) 7 8 9 10 11 12
FIRST FRAME EXTENSION MEMBER (EX:TRUSS) (140) 13 14 15 16 17 18
SECOND FRAME EXTENSION MEMBER (EX:CYLINDER) (150) 19 20 21 22 23 24
THIRD FRAME EXTENSION MEMBER (EX:FIXED FRAME) (154) 25 26 27 28 29 30
FOURTH FRAME EXTENSION MEMBER (EX:MOVEABLE FRAME) (192) 31 32 33 34 35 36
CONNECTED TO EXTENSION TABLE
CONNECTED TO BASE MODULE AND EXTENSION TABLE
CONNECTED TO MAIN FRAME

212

FIG.42

FIG.43

100



FIG.44


START
242
243
BALES IN A STACK = X
246
RECEIVE A BALE ON THE LOAD BED
248
HAS THE BALE REACHED A PREDETERMINED POSITION ON THE LOAD BED ?
250
NO
YES
TRANSFER THE BALES ACROSS THE LOAD BED
366
252
ARE ANY BALES RAISED ABOVE THE LOAD BED ?
254
NO
YES
LOWER THE RAISED BALE(S) ONTO THE RECEIVED BALE ON THE LOAD BED
256
BALES IN THE STACK = X ?
258
YES
NO
RAISE A PARIAL STACK OF BALES ABOVE THE LOAD BED
264
DISCHARGE THE STACKS OF BALES FROM THE LOAD BED TO THE GROUND SURFACE
262
TRANSFER THE STACK OF BALES ACROSS THE LOAD BED
262
READY TO DISCHARGE THE STACKS OF BALES ?
260
NO
YES


100
270
272
274
276
186
336
338
113
109
120
110
128
111
108
278
280
282
284
286
288
290
292
294
296
298
1-6
300
1,2
3,4
225
202
224
223
203
226

FIG.45


100
113
186
109
120
128
111
302
304
305
308
336
338
310
312
314
316
318
320
322
324
326
328
330
1-4

FIG.46


225
202
224
223
203
226

FIG.47


225
203
201
222
221
226
334
332
336
340
342
340
340
342
340
336
113
362
338
352
362
354
340
340
352
109
119
352
344
352
338
342
344
338
103
111
146
344
117
112
100
338
356
344
346
128
120
134
108


337
114
117
201
221
202
224
223
222
348
338
340
338
124
336
336
342
350
350
342
340
186
356
358
113
186
346
336
340
336
146
110
108
342
342
100
118
350
340
340
350
116
332
119
160

FIG.48

FIG.49


225
203
224
223
202
226
100
334
332
340
340
336
336
362
362
338
338
109
336
362
336
126
360
186
113
360
124
336
340
340
336
116
118
120
146
362
350
362
108
110
134
114
111
128
119
160
112


370
368
366
362
176
104
102
336
362
336
362
122
124
108
172
116
360
186
186
184
134
332
114
112
111
113
174
126
123
178
106
102
120
110
128
100
364
372
223
203
202
225
226
224

FIG.50


100
102
104
176
136
122
116
103
114
336
372
172
186
366
119
168
184
336
336
160
117
118
366
174
110
138
123
178
134
106
102
225
202
223
201
226
224

FIG.51

FIG.52


START
374
375
BALES IN A STACK = X
376
RECEIVE A BALE ON THE LOAD BED
HAS THE BALE REACHED A PREDETERMINED POSITION ON THE LOAD BED ?
378
NO
YES
394
TRANSFER THE BALES ACROSS THE LOAD BED
380
390
DISCHARGE THE STACKS OF BALES FROM THE LOAD BED TO THE GROUND SURFACE
382
ARE ANY BALES LOWERED BELOW THE LOAD BED ?
NO
384
YES
RAISE THE LOWERED BALE(S) UNDERNEATH THE RECEIVED BALE ON THE LOAD BED
394
TRANSFER THE STACK OF BALES ACROSS THE LOAD BED
NO
386
BALES IN THE STACK = X ?
YES
388
READY TO DISCHARGE THE STACKS OF BALES ?
YES
392
NO
LOWER A PARIAL STACK OF BALES BELOW THE LOAD BED

FIG.53


400
1
109
186
113
110
128
108
100
402
120
186
404
406
2
1,2
3
408
410
412
414
416
418
420
422
3.4
424
426
428
5
430
432
434
6
436
5,6
438
440
1-6
444
225
224
202
223
203
226

FIG.54


202
203
460
174
458
113
456
460
172
454
454
109
456
118
116
120
360
184
360
134
110
108
114
448
186
452
446
112
448
128

FIG.55


458
454
113
460
174
452
186
360
172
458
456
360
454
456
118
116
452
460
332
120
448
111
114
184
119
134
110
120
108
448
128
112
446

FIG.56


201
203
113
184
168
186
798
456
119
450
452
448
450
117
111
146
108
120
112
128

FIG.57


113
332
450
109
452
456
456
119
184
117
120
112
798
128
114
450
111
168
186
448
450

FIG.58


202
201
117
103
120
120
126
124
798
120
452
120
452
120
146
146
143
110
186
186
108
134
458
454
454
458
460
118
456
460
448
113
360
119
114
360
448
332
456
160
100

FIG.59


START
462
TOTAL NAMBER OF BALES IN A RAISED PARTIAL STASK OF BALES = X
469
TOTAL NUMBER OF BALES IN A LOWERED PARTIAL STACK OF BALES = Y
466
TOTAL NUMBER OF BALES BETWEEN THE RAISED PARTIAL STACK OF BALES X, AND THE LOWERED PARTIAL STACK OF BALES, Y,=1
468
TOTAL NUMBER OF BALES IN A COMPITE STACK = X+Y+1=Z
470
TOTAL BALE ACCUMULATING CAPACITY OF A LOAD BED = C
472
RECEIVE A BALE ON THE LOAD BED.
474
HAS THE BALE REACHED A PREDETERMINED POSITION ON THE LOAD BED INDICATING THAT THE BALE IS FULLY FORMED ?
476
NO
YES
A
B
C
D
INCRENCMENT BALE COUNTER
494
ANY BALE LOWERED BELOW THE LOAD BED ?
496
NO
YES
RAISE THE LOWERED BALES TO DIRECTLY CONTACT A BOTTOM SIDE OF THE LAST BALE RECEIVED
498
263

FIG.59


C
A
YES
500
ANY BALES RECEIVED ABOVE THE LOAD BED ?
NO
LOWER THE RAISED BALES TO DIRECTLY CONTACT A TOP SIDE OF THE LAST BALE RECEIVED
504
IS THE NUMBER OF BALES RECEIVED = C ?
NO
YES
508
DISCHARGE THE STACK OF BALES FROM THE LOAD BED TO A GROUND SURFACE
506
TRANSFER THE COMPLETE STACK OF BALES ACROSS THE LOAD BED
488
ANY BALES ALREADY LOWERED BELOW THE LOAD BED ?
NO
YES
490
RAISE THE LOWERED BALES TO DIRECTLY CONTACT A BOTTOM SIDE OF THE LAST BALE RECEIVED
492
LOWER A PARTIAL STACK OF BALES BELOW THE LOAD BED
B
A
YES
478
DOES THE NUMBER OF BALES RECEIVED = Z ?
NO
480
DESIRE TO RAISE OR LOWER THE LAST BALE RECEIVED ?
LOWER
RAISE
482
ANY BALES ALREADY RAISED ABOVE THE LOAD BED ?
NO
YES
484
LOWER THE RAISED BALES TO DIRECTLY CONTACT A TOP SIDE OF THE LAST BALE RECEIVED
486
RAISE A PARTIAL STACK OF BALES ABOVE THE LOAD BED
263

FIG.60


364
1
109
113
110
114
108
446
100
111
1
512
336
336
110
108
2
514
110
120
108
2
516
110
108
518
3
520
522
1,2,3
524
1,2,3
526
4
113
528
4
530
5
532
5
534
6
536
4
538
4,6,5
4,6,5
540
202
203


202
203
560
562
564
566
568
570
572
574
576
578
580
582
584
586
588
590
1,2,3
4,6,5
100
110
108
120
112
114
116
128

FIG.61


592
7
594
596
8
598
118
128
110
120
100
108
600
9
602
8
604
7,9,8
606
1-9
116
114
608
202
203

FIG.61

FIG.62A


610
START
230
611
612
RECEIVE A PLURALITY OF BALES ON A FIRST BALE RECEIVING PORTION OF A FIRST SUBSTANTIALLY PLANER LOAD BED ALONG A BALE RECEIVING AXIS, WHEREIN THE FIRST BALE RECEIVING PORTION IS DISPOSED WITHIN A PERIMETER OF THE FIRST LOAD BED, WHEREIN THE BALE RECEIVING AXIS IS DISPOSED SUBSTANTIALLY PARALLEL TO A LONGITUDINAL AXIS OF THE ACCUMULATOR, AND WHEREIN THE BALES ARE RECEIVED IN A BALE RECEIVING DIRECTION ESSENTIALLY OPPOSITE TO AN ACCUMULATOR TRAVELING DIRECTION.
614
TRANSFER THE BALES ACROSS THE FIRST LOAD BED ALONG A BALE TRANSFERRING AXIS RESPONSIVE TO RECEIVING THE BALES ON A FIRST LOAD BED TO ACCUMULATE THE BALES ON THE FIRST LOAD BED,WHEREIN THE BALE TRANSFERRING AXIS IS AND DISPOSED HORIZONTALLY TRANSVERSE TO THE BALE RECEIVING AXIS AND IS DISPOSED SUBSTANTIALLY PARALLEL TO A LATERAL AXIS OF THE ACCUMULATOR.
RECEIVING THE PLURALITY OF BALES ON A SECOND BALE RECEIVING PORTION OF A SECOND SUBSTANTIALLY PLANAR LOAD BED, WHEREIN THE SECOND BALE RECEIVING PORTION IS DISPOSED WITHIN A PERIMETER OF THE SECOND LOAD BED, WHEREIN THE FIRST LOAD BED IS DISPOSED SUBSTANTIALLY PARALLEL TO THE SECOND LOAD BED AND IS VERTICALLY DISPLACED RELATIVE TO THE SECOND LOAD BED ALONG A COMMON LOAD BED AXIS, WHEREIN THE COMMON LOAD BED AXIS IS DISPOSED VERTICALLY TRANSVERSE TO THE BALE RECEIVING AXIS AND THE BALE TRANSFERRING AXIS.
616
A

FIG.62


A
618
TRANSFER THE BALES ACROSS THE SECOND LOAD BED ALONG THE BALE TRANSFERING AXIS RESPOSIVE TO RECEIVING THE BALES ON THE SECOND LOAD BED TO ACCUMULATE THE BALES ON THE SECOND LOAD BED.
620
DISCHARGE THE BALES ACUMMULATED ON THE FIRST LOAD BED AND THE BALES ACUMMULATED ON THE SECOND LOAD BED FROM THE FIRST LOAD BED AND THE SECOND LOAD BED RESPECTIVELY TO A GROUND SURFACE ALONG A BALE DISCHARGING AXIS, SUBSTENTIALLY PARELLEL TO THE LONGITUDINAL AXIS, AND IN A BALE DISCHARGING DIRECTION, ESSENTIALLY OPPOSITE TO THE ACCUMULATOR TRAVELING DIRECTION, WHERIN THE BALES ARE DISCHARGED FROM THE FIRST LOAD BED AND THE SECOND LOAD BED EITHER SIMULTANEOUSLY TO FORM STACKS OF BALES ON THE GROUND SURFACE OR FROM ONE OF THE FIRST LOAD BED AND THE SECOND LOAD BED AT A TIME TO FORM A SINGLE LAYER OF BALES ON THE GROUND SURFANCE.
END
622

FIG.63


START
624
BALE = X
626
TOTAL NUMBER OF LOAD BALES = Y
628
TOTAL NUMBER OF MOVEABLE LOAD BEDS = Y-1
630
TOTAL BALE ACCUMULATING CAPACITY FOR EACH OF TOTAL NUMBER OF LOAD BEDS, Y, - C.
632
MOVE ALL THE MOVEABLE LOAD BEDS, Y - 1, TO A BALE RECEIVING POSITION.
634
636
SET Y = 1.
654
X = X + 1.
638
RECEIVING A BALE, X, ON TABLE, Y.
640
HAS THE BALE X REACHED A PREDETERMINED POSITION ON THE LOAD BED, Y ?
NO
YES
A
B
C

FIG. 63


A
YES
642
HAS THE LOAD BED, Y, REACHED ITS BALE ACCUMULATING CAPACITY, C?
NO
648
TRANSFER THE BALE, X, ACROSS THE LOAD BED, Y, TO ACCUMULATE THE BALE ON THE LOAD BED, Y.
B
C
YES
644
HAVE EACH OF THE TOTAL NUMBER OF LOAD BEDS, Y, REACHED ITS BALE ACCUM-ULATING COPCITY, C?
NO
650
RAISE LOAD BED, Y, ABOVE LOAD BED, Y+1. TO A BALE LOADED POSITION.
652
Y = Y+1
YES
646
DISCHARGE THE BALES FROM EACH OF THE LOAD BEDS, Y, EITHER OF THE LOAD BEDS, Y, EITHER SIMULTANEOUSLY FROM EACH LOAD BED TO FORM STACKS OF BALES ON THE GROUND SURFACE OR FROM ONE LOAD BED AT A TIME TO FORM A SINGLE LAYER OF BALES ON THE GROUND SURFACE.

FIG.64


656
1/T1
658
1/T1
660
2/T1
662
2/T1
120
110
128
111
108
100
664
3/T1
666
1,3,2/T1
668
4/T2
670
4/T2
672
5/T2
674
5/T2
676
6/T2
100
202
203
678
1,3,2/T1
4,6,5/T2
680
682
T1
113
120
4,6,5/T2
1,3,2/T1
675
677
679
681

FIG.65


203
202
692
698
160
692
684
694
1
3
5
4
2
694
178
123
6
8
10
9
7
126
174
184
186
172
122
176
113
686
690
686
116
690
116
113
122
126
120
118
114
184
124
110
111
686
102
102
128
112
134
108
119
100


201
202
131
138
694
692
117
692
694
136
129
122
684
123
798
688
186
690
178
686
174
686
172
690
176
688
686
168
686
146
110
186
120
686
108
184
694
120
102
123
694
692
131
118
126
114
119
116
124
692
129
122
102
100

FIG.66

FIG.67


203
202
698
160
332
694
692
1
3
5
4
2
700
178
123
131
109
6
126
8
174
10
184
9
172
7
122
129
116
106
120
110
124
690
686
111
126
114
134
108
102
128
112
100
104

FIG.68


201
202
100
138
131
694
692
702
123
117
103
688
690
694
692
136
129
702
684
122
798
700
686
702
172
176
686
178
174
686
120
146
110
168
120
102
118
122
106
694
131
114
126
704
119
700
184
124
700
102
692
104
700
122
113
100


706
START
708
TOTAL NUMBER OF FIXED LOAD BEDS = Y
710
TOTAL NUMBER OF FIXED LOAD BEDS RAISED ABOVE A BALE RECIEVING LOAD BED = Y-1
712
TOTAL BALE ACCUMULATING CAPACITY FOR THE SIDE OF EACH LOAD BED = C1
714
TOTAL BALE ACCUMULATING CAPACITY FOR A CENTER PORTION OF EACH LOAD BED = C-2
716
TOTAL BALE ACCUMULATING CAPACITY FOR EACH OF THE ENTIRE LOAD BED = C3 = C1+C2
718
RECIEVE A PLURALITY OF BALES ON THE BALE RECIEVING LOAD BALE
720
HAS THE BALE RECIEVING LOAD BED REACHED ITS BALE ACCUMULATING CAPACITY; C1
NO
YES
ACCUMULATE THE BALES ON THE SIDE OF THE BALE RECIEVING THE LOAD.
730
A
B

FIG.69A


A
A
YES
722
HAS EACH OF THE RAISED LOAD BEDS,Y-1 REACHED IT BALE ACCUMULATING CAPACITY,C1 ?
NO
732
ACCULATE THE BALES ON THE SIDES OF EACH RAISED LOAD BED RESPONSIVE TO MOVING A BALE ELEVATING PLATFORM ALONG A VERTICAL AXIS BETWEEN A BALE RECEIVING POSITION AND A BALE TRANSFERRING POSITION
B
YES
724
HAS EACH OF THE RAISED LOAD BEDS Y-1, REACHED ITS BALE ACCUMULATING CAPACITY, C2 ?
NO
734
ACCULATE THE BALES ON THE SIDES OF EACH RAISED LOAD BED RESPONSIVE TO MOVING A BALE ELEVATING PLATFORM ALONG A VERTICAL AXIS BETWEEN A BALE RECEIVING POSITION AND A BALE TRANSFERRING POSITION
YES
726
HAS THE BALE RECEIVING LOAD BED REACHED ITS BALE ACCUMULATING COPACITY, C2 ?
NO
736
ACCUMULATE THE BALES ON THE CENTER OF THE BALE RECEIVING LOAD BED
728
DISCHARGE THE BALES FROM EACH OF THE LOAD BED, Y EITHER SIMULATANEOUSLY FROM EACH LOAD BED TO FORM STACKS OF BALES ON THE GROUND SURFACE OR FROM ONE LOAD AT A TIME TO FORM A SINGLE LAYER OF BALES ON THE GROUND SURFACE

FIG.69B

FIG.70


738
1/T2
740
1/T2
742
2/T2
744
2/T2
113
120
110
128
108
100
746
3/T2
748
3/T2+T1
750
3/T1
752
T1+T2
754
4/T2
756
4/T2+T1
758
4/T1
760
T1+T2
762
5/T2
764
5/T2+T1
768
/T2
770
6/T2
772
3,5,4/T1
1,6,2/T2
774
776
T2
778
T1
T2

FIG. 71


100
780
203
202
692
692
332
782
782
694
694
186
109
460
458
458
460
456
456
118
360
116
113
146
454
114
119
454
120
110
134
108
128
112

FIG. 72


100
203
202
692
692
332
186
782
109
782
360
694
694
114
119
458
458
118
454
454
116
456
460
460
124
126
456
113
146
120
111
110
134
108
128
112
160

FIG. 73


100
202
201
160
692
117
692
694
694
458
458
454
454
186
126
124
146
110
108
692
118
692
694
114
119
694
116
112

FIG. 74


785
784
START
786
RECEIVE A PLURALITY OF BALES, INCLUDING A FIRST BALE FOLLOWED BY A SECOND BALE, ON A LOAD BED AT A FIRST RATE OF SPEED.
788
HAS THE FIRST BALE REACHED A FIRST PREDETERMINED POSITION ON THE LOAD BED INDICATING THAT THE FIRST BALE IS FULLY FORMED ?
NO
YES
790
ADVANCE THE FIRST BALE ONTO THE LOAD BED AT A SECOND RATE OF SPEED, GREATER THAN THE FIRST RATE OF SPEED, TO SEPARATE THE FIRST BALE FROM THE SECOND BALE BY A PREDETERMINED DISTANCE.
792
HAS THE FIRST BALE REACHED A SECOND PREDETERMINED POSITION ON THE LOAD BED INDICATING THAT THE FIRST BALE HAS ADVANCED THE PREDETERMINED DISTANCE ?
NO
YES
794
STOP THE ADVANCEMENT OF THE FIRST BALE ONTO THE LOAD BED.
796
HANDLE THE FIRST BALE RECEIVED AND ADVANCED ON THE LOAD BED IN A FIRST AMOUNT OF TIME LESS THAN A SECOND AMOUNT OF TIME REQUIRED FOR THE SECOND BALE TO MOVE THROUGH THE PREDETERMINED DISTANCE

FIG. 75


100
203
201
798
806
802
S1
801
803
109
184
168
119
113
117
103
805
114
111
108
800
120
112
128
S2
804

FIG. 76


100
203
201
798
801
803
109
168
184
119
807
113
103
117
114
111
805
800
120
108
112
128

FIG. 77


100
203
201
798
801
808
810
812
803
109
184
168
119
113
114
111
108
128
112
805
800
120
117
103

FIG. 78


203
201
798
806
802
S1
109
184
168
814
805
103
119
805
113
117
114
807
111
120
108
112
128
S2
804

FIG. 79


203
201
798
109
184
168
805
814
103
119
113
117
114
805
111
807
108
112
128

FIG. 80


203
201
100
808
798
810
109
812
168
184
119
103
113
117
114
111
108
805
807
814
805
112
120
128

830

FIG.81


816
START
(INPUT RECEIVED DURING RECEIVING)
818
RECEIVING AN INPUT CONDITION
(INPUT RECEIVED BEFORE RECEIVING)
820
RECEIVING A PLURALITY OF BALES ON THE AGRICULTURAL BALE ACCUMULATOR.
DETERMINING A DYNAMIC ARRANGEMENT FOR THE PLURALITY OF BALES RECEIVED ON THE AGRICULTURAL BALE ACCUMULATOR RESPONSIBLE TO THE INPUT CONDITION.
822
ACCUMULATING THE PLURALITY OF BALES RECEIVED ON THE AGRICULTURAL BALE ACCUMULATOR RESPONSIVE TO THE DETERMINED DYNAMIC ARRANGEMENT.
824
826
READY TO DISCHARGE THE ACCUMULATED BALES FROM THE ACCUMULATOR TO A GROUND SURFACE?
NO
YES
DISCHARGE THE ACCUMULATED BALES.
828

FIG 82


332
203
202
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
102
105
104
106
107
108
110
112
113
114
116
118
120
122
123
125
127
128
186

FIG. 83

	DYNAMIC ARRANGEMENT FOR THE ACCUMULATION OF BALES						
834 HORIZONTAL BALE ACCUMULATING CAPACITY (NUMBER OF BALES)	1	2	3	4	5	6	7
836 VERTICAL BALE ACCUMULATING CAPACITY (NUMBER OF BALES)							
1	21	15,21	15,21,18	9,15,21, 18	9,15,21, 18,12	3,9,15 21,18,12	3,9,15 21,18,12 6
2	20,21	14,15; 20,21	14,15; 20,21 17,18	8,9;14, 15;20,21; 17,18	8,9;14, 15;20,21; 17,18;11 12	2,3;8 9;14,15; 20;21,17, 18;11,12;	2,3;8, 9;14,15; 20,21;17, 18;11,12; 5,6
3	19,20; 21	13,14, 15;19, 20,21	13,14,15; 19,20,21; 16,17,18 (MAXIMUM LOAD BED BALE CARRYING CAPACITY)	7,8,9; 13,14,15; 19,20,21; 16,17,18	7,8,9; 13,14,15; 19,20,21; 16,17,18; 10,11,12	1,2,3; 7,8,9; 13,14,15; 19,20,21; 16,17,18; 10,11,12	1,2,3; 7,8,9; 13,14,15; 19,20,21; 16,17,18; 10,11,12; 4,5,6 (MAXIMUM ACCUMULATOR BALE CARRYING CAPACITY)

839

FIG. 84


838
START
840
RECEIVING A PLURALITY OF BALES ON A LOAD BED OF AN AGRICULTURAL BALE ACCUMULATOR AS THE ACCUMULATOR TRAVELS ACROSS A GROUND SURFACE HAVING A DEGREE OF LEVELNESS WHICH VARIES RELATIVE TO A HORIZONTAL PLANE.
842
ACCUMULATING THE PLURALITY OF BALES ON THE LOAD BED AT PREDETERMINED POSITION ON THE LOAD BED AS ACCUMULATOR TRAVELS ACROSS THE GROUND SURFACE.
844
STABILIZING THE PLURALITY OF BALES ACCUMULATED ON THE LOAD BED TO ENCOURAGE THE PLURALITY OF BALES ACCUMULATED ON THE LOAD BED AT THE PREDETERMINED POSITION ON THE LOAD BED TO REMAIN LOCATED AT THE PREDETERMINED POSITION ON THE LOAD BED AS THE ACCUMULATOR IS TRANSPORTED ACROSS THE GROUND SURFACE, WITHOUT USING A BALE STABILIZATION STRUCTURE PERMANENTLY DISPOSED ABOVE THE LOAD BED.
846
END

FIG.85A


START
848
DETERMINE A FIRST MEASURE OF LEVELNESS OF THE LOAD BED RELATIVE TO THE HORIZONTAL PLANE ALONG A LONGITUDINAL AXIS OF THE LOAD BED
850
852
IS THE FIRST MEASURE OF LEVELNESS DESIRABLE ?
NO
YES
854
MAINTAIN THE LEVELING POSITION, WITHIN THE FIRST RANGE OF LEVELING POSITIONS, ALONG THE LONGITUDINAL AXIS RELATIVE TO THE HORIZONTAL PLANE
DETERMINE A SECOND MEASURE OF LEVELNESS OF THE LOAD BED RELATIVE TO THE HORIZONTAL PLANE ALONG A LATERAL AXIS OF THE LOAD BED
838
A
B
853
856
DOES THE FIRST MEASURE OF LEVELNESS INDICATE THAT THE LOAD BED HAS REACHED A MAXIMUM ADJUSTMENT LIMIT WITHIN FIRST PREDETERMINED RANGE OF LEVELING POSITIONS ALONG THE LONGITUDINAL AXIS ?
NO
YES
858
DOES THE FIRST MEASURE OF LEVELNESS INDICATE THAT A FRONT END OF THE LOAD BED OR A REAR END OF THE LOAD BED IS HIGHER RELATIVE TO THE HORIZONTAL PLANE ?
FRONT END
REAR END
860
CHANGE A LEVELING POSITION OF THE LOAD BED ALONG THE LONGITUDINAL AXIS, WITHIN THE FIRST PREDETERMINED RANGE OF LEVELING POSITION, BY LOWERING A FRONT END OF THE LOAD BED RELATIVE TO A HORIZONTAL PLANE, OR IS RAISING A REAR END OF THE LOAD BED RELATIVE TO THE HORIZONTAL PLANE
862
CHANGE A LEVELING POSITION OF THE LOAD BED ALONG THE LONGITUDINAL AXIS, WITHIN THE FIRST PREDETERMINED RANGE OF LEVELING POSITION, BY LOWERING A FRONT END OF THE LOAD BED RELATIVE TO A HORIZONTAL PLANE, OR IS RAISING A REAR END OF THE LOAD BED RELATIVE TO THE HORIZONTAL PLANE
52/88

FIG.85B


B
A
864
IS THE SECOND MEASURE OF LEVELNESS DESIRABLE ?
NO
YES
866
MAINTAIN THE LEVELING POSITION, WITHIN THE SECOND RANGE OF LEVELING POSITIONS, ALONG THE LATERAL AXIS RELATIVE TO THE HORIZONTAL PLANE
870
DOES THE SECOND MEASURE OF LEVELNESS INDICATE THAT A RIGHT SIDE OF THE LOAD BED OR A LEFT SIDE OF THE LOAD BED HIGHER RELATIVE TO THE HORIZONTAL PLANE ?
LEFT SIDE
RIGHT SIDE
882
DOES THE SECOND MEASURE OF LEVELNESS INDICATE THAT THE LOAD BED HAS REACHED MAXIMUM ADJUSTMENT LIMIT WITHIN THE SECOND PREDETERMINED RANGE OF LEVELING POSITION ALONG THE LATERAL AXIS ?
YES
NO
884
IS THERE ANY BALE CARRYING CAPACITY AVAILABLE ON THE LEFT (HIGH) SIDE OF THE ACCUMULATOR ?
NO
YES
886
TRANSFER THE BALE(S) TO THE LEFT (HIGH) SIDE OF THE ACCUMULATOR, AT THE APPROPRIATE TIME
888
CHANGE A LEVELING POSITION OF THE LOAD BED ALONG THE LATERAL AXIS, WITHIN THE SECOND PREDETERMINED RANGE OF LEVELING POSITION, BY LOWERING THE RIGHT SIDE OF THE LOAD BED AND/OR RAISING THE LEFT SIDE OF THE LOAD BED RELATIVE TO THE HORIZONTAL PLANE
872
DOES THE SECOND MEASURE OF LEVELNESS INDICATE THAT THE LOAD BED HAS REACHED MAXIMUM ADJUSTMENT LIMIT WITHIN THE SECOND PREDETERMINED RANGE OF LEVELING POSITION ALONG THE LATERAL AXIS ?
NO
YES
CHANGE A LEVELING POSITION OF THE LOAD BED ALONG THE LATERAL AXIS, WITHIN THE SECOND PREDETERMINED RANGE OF LEVELING POSITION, BY LOWERING THE RIGHT SIDE OF THE LOAD BED AND/OR RAISING THE LEFT SIDE OF THE LOAD BED RELATIVE TO THE HORIZONTAL PLANE
878
TRANSFER THE BALE(S) TO THE RIGHT SIDE OF THE LEFT SIDE OF THE ACCUMULATOR AT THE APPROPRIATE TIME.
880,894
874
IS THERE ANY BALE CARRYING CAPACITY AVAILABLE ON THE RIGHT (HIGH) SIDE OF THE ACCUMULATOR ?
NO
YES
896
MAINTAIN THE LEVELING POSITION, WITHIN THE SECOND RANGE OF LEVELING POSITION, ALONG THE LATERAL AXIS RELATIVE TO THE HORIZONTAL PLANE
898
TRANSFER THE BALE(S) TO THE LEFT (LOW) SIDE OF THE ACCUMULATOR, AT THE APPROPRIATE TIME
876
TRANSFER THE BALE(S) TO THE RIGHT (HIGH) SIDE OF THE ACCUMULATOR, AT THE APPROPRIATE TIME
890
MAINTAIN THE LEVELING POSITION, WITHIN THE SECOND RANGE OF LEVELING POSITION, ALONG THE LATERAL AXIS RELATIVE TO THE HORIZONTAL PLANE
TRANSFER THE BALE(S) TO THE RIGHT (LOW) SIDE OF THE ACCUMULATOR, AT THE APPROPRIATE TIME
892


221
201
203
222
902
128
900
906
113
113
108

FIG. 86


203
201
221
222
202
902
128
900
906
113
113
108
110

FIG. 87

FIG. 88


100
904
203
202
126
118
109
114
116
124
113
112
899
120
111
128
910
110
908
134
108
910

FIG. 89


100
904
203
202
118
114
116
899
126
124
113
112
120
109
908
910
128
108
910
110

FIG. 90


203
201
100
899
902
113
116
109
112
103
117
119
111
912
914
910
124
120
108
128

FIG. 91


203
201
100
899
902
116
119
124
109
103
113
112
914
111
120
912
117
128
910
108

FIG. 92


917
916
START
918
BALE CARRYING CAPACITY OF THE LOAD BED=C-1
BALE CARRYING CAPACITY OF ALL EXTENSION TABLES=C2
BALE CARRYING CAPACITY OF THE ACCUMULATOR=C3=C1+C2
920
PIVOTING THE LOAD BED TO A BALE RECEIVING POSITION
922
MOVE EXTENSION TABLES ON THE RIGHT AND LEFT AND LEFT SIDE OF THE LOAD BED TO A STOWED POSITION
924
RECEIVING A PLURALITY OF BALES THE LOAD BED
926
HAS THE BALE REACHED A PREDET-ERMINED POSITION ON THE LOAD BED INDICATING THAT THE BALE IS FULLY FORMED ?
YES
NO
928
IS THE STACK OF BALES COMPLETE ?
NO
YES
930
C1=MAXIMUM ?
NO
YES
932
C2=MAXIMUM ?
NO
YES
940
READY TO TRANSFER THE BALE(S) TOWARDS A RIGHT SIDE OR A LEFT SIDE OF THE LOAD BED ?
RIGHT
LEFT
942
TRANSFER THE BALE(S) ACROSS THE LOAD BED AND EXTENSION TABLES TOWARDS THE RIGHT SIDE OF THE LOAD BED
944
TRANSFER THE BALE(S) ACROSS THE LOAD BED AND EXTENSION TABLES TOWARDS THE RIGHT SIDE OF THE LOAD BED
946
READY TO TRANSFER THE BALE(S) TOWARDS A RIGHT SIDE OR A LEFT SIDE OF THE LOAD BED ?
RIGHT
LEFT
948
MOVE THE EXTENSION TABLE ON THE LEFT SIDE OF THE LOAD BED FROM A STOWED POSITION TO AN UNSTOWED POSITION
950
MOVE THE EXTENSION TABLE ON THE LEFT SIDE OF THE LOAD BED FROM A STOWED POSITION TO AN UNSTOWED POSITION
934
READY TO DISCHARGE THE BALES ON THE LOAD BED TO A GROUND SURFACE ?
NO
YES
936
DISCHARGE THE BALES FROM THE LOAD BED TO THE GROUND SURFACE BY PIVOTING THE LOAD BED TO THE BALE DISCHARGING POSITION


952
954
956
958
960
962
964
966
968
970
972
974
976
978
980
982
984
986
988
990
992
994
100
102
108
109
110
111
112
113
116
203
202

FIG. 93

FIG. 94


203
202
998
998
107
1
3
105
109
186
127
125
996
102
2
5
4
104
106
899
123
102
113
122
126
111
116
124
112
120
118
114
119
110
108
134
128

FIG. 95


203
202
332
1
5
9
7
3
998
998
107
2
6
10
8
4
105
109
186
127
123
125
106
126
118
114
116
124
104
996
102
111
119
120
122
899
113
110
102
128
112
108

FIG. 96


203
202
332
1
5
9
13
11
7
3
998
998
2
6
10
14
12
8
4
996
109
186
107
105
127
123
126
118
116
124
122
125
106
104
102
899
102
114
111
119
110
112
113
120
108
128
160

FIG 97


203
202
100
1004
996
1002
1000
109
113
111
112
104
122
105
125
102
899
128
120
119
116
108

FIG 98


203
202
100
996
1006
109
113
104
125
105
134
122
899
102
128
112
111
116
108
119

FIG. 99


1007
1008
START
ACCUMULATE A BALE ON A LOAD BED AT A LOCATION ON THE LOAD BED ADJACENT TO A LOAD BED EXTENSION TABLE MECHANICALLY COUPLED TO THE LOAD BED AND MOVEABLE BETWEEN A STOWED POSITION TO STABILIZE THE BALE ON THE LOAD BED AND AN UNSTOWED POSITION TO RECEIVE THE BALE ON THE LOAD BED EXTENSION TABLE FROM THE LOCATION LOAD BED.
1009
MOVE THE LOAD BED EXTENSION TABLE FROM THE STOWED POSITION TO THE UNSTOWED POSITION RESPONSIVE TO A COUNTERWEIGHT FORCE PROVIDED BY A WEIGHT OF THE BALE ON THE LOAD BED AT THE LOCATION ON THE LOAD BED ADJACENT TO THE LOAD BED EXTENSION TABLE AND RESPONSIVE TO THE BALE BEING TRANSFERRED FROM THE LOCATION ON THE LOAD BED ON TO THE LOAD BED EXTENSION TABLE.
1010
1011
END

FIG.100


1010
START FROM STEP 946 IN FIG. 92
1012
EXERT A FIRST BIAS FORCE ON THE LOAD BED EXTENSION TABLE TO CAUSE THE LOAD BED EXTENSION TABLE TO MOVE FROM THE UNSTOWED POSITION TO THE STOWED POSITION
1013
SECURE A FIRST LATCH TO HOLD THE LOAD BED EXTENSION TABLE IN THE STOWED POSITION
1014
PRODUCE A COUNTERWEIGHT FORCE, PROVIDED BY A WEIGHT OF A BALE ON A LOAD BED, AT A LOCATION ON THE LOAD BED ADJACENT TO THE LOAD BED EXTENSION TABLE
1015
APPLY THE COUNTERWEIGHT FORCE AGAINST FIRST BIAS FORCE TO SUBSTANTIALLY REDUCE THE EFFECT OF THE FIRST BIAS FORCE
1016
EXERT A SECOND BIAS FORCE ON THE LOAD BED EXTENSION TABLE TO CAUSE THE LOAD BED EXTENSION TABLE TO MOVE FROM THE STOWED POSITION TO THE UNSTOWED POSITION
1017
1018
RELEASE THE FIRST LATCH RESPONSIVE TO THE BALE BEING TRANSFERRED FROM THE LOCATION ON THE LOAD BED ADJACENT TO THE LOAD BED EXTENSION TABLE ON TO THE LOAD BED EXTENSION TABLE TO PERMIT THE SECOND BIAS FORCE TO MOVE THE LOAD BED EXTENSION TABLE FROM THE STOWED POSITION TO THE UNSTOWED POSITION
1019
SECURE A SECOND LATCH TO HOLD THE LOAD BED EXTENSION TABLE IN THE UNSTOWED POSITION
1020
CONTINUE TO STEP 944 OR STEP 948 IN FIG. 92
1021
START FROM STEP 936 IN FIG. 92
1022
RELEASE THE SECOND LATCH RESPONSIVE TO THE LOAD BED PIVOTING TO THE BALE RECEIVING POSITION AFTER DISCHARGING THE BALES FROM THE LOAD BED TO PERMIT THE FIRST BIAS FORCE TO MOVE THE LOAD BED EXTENSION TABLE FROM THE UNSTOWED POSITION TO THE STOWED POSITION
1023
CONTINUE TO STEP 924 IN FIG. 92

FIG. 101



FIG. 102




203
202
1014
F SPRING-DOWN
1018
LATCH IN
DOWN POSITION
1026
LATCH IN UP
POSITION
104
F TABLE
1022
104
1024
122
1036
1034
F SPRING-UP
1016
1032
1030
116
1028
F BALE
1020
1038
109
100

FIG. 103

FIG. 104A


1039
1040
START
1041
RECEIVE A BALE ON A BALE RECEIVING PORTION OF A LOAD BED AT A FIRST RATE OF SPEED ALONG A BALE RECEIVING AXIS
1042
HAS THE BALE REACHED A PREDETERMINED POSITION ON THE LOAD BED ALONG A BALE RECEIVING AXIS ?
NO
YES
1043
READY TO DISCHARGE THE BALES FROM THE LOAD BED TO THE GROUND SURFACE ?
NO
1046
TRANSFER THE BALES ACROSS THE LOAD BED
YES
1045
WILL A NEXT BALE DUE TO RECEIVE ON THE LOAD BED INTERFERE WITH AN ENTRY REGION OF THE LOAD BED WHEN THE LOAD BED MOVES FROM THE BALE RECEIVING PORTION TO THE BALE DISCHARGING POSITION ?
NO
YES
A
B
F


B
A
1044
1049
WILL THE NEXT BALE TO BE RECEIVED ON THE LOAD BED INTERFERE WITH THE ENTRY REGION OF THE LOAD BED WHEN THE LOAD BED MOVED FROM THE BALE DISCHARGE POSITION TO THE BALE RECEIVING POSITION ?
NO
YES
1050
PROVIDE A SPACE (GAP) ALONG THE BALE RECEIVING AXIS IN THE ENTRY REGION OF THE LOAD BED WITHOUT SUPPORTING THE NEXT BALE TO BE RECEIVED ON THE LOAD BED. (DYNAMIC: MOVEABLE BALE SUPPORT MEMBER, STATIC: NO LOAD BED SUPPORT IN THE ENTRY REGION OF THE LOAD BED.)
1051
PIVOT THE LOAD BED FROM THE BALE DISCHARGING POSITION TO THE BALE RECEIVING POSITION, WHERE IN THE LOAD BED PIVOTS FROM THE BALE RECEIVING POSITION TO THE BALE DISCHARGING POSITION AND LOCK TO THE BALE RECEIVING POSITION IN A FIRST AMOUNT OF TIME LESS THAN A SECOND AMOUNT OF TIME REQUIRED FOR THE NEXT SUCCESSIVE BALE TO MOVE THROUGH THE SPACE AT THE FIRST RATE OF SPEED ALONG THE BALE RECEIVING AXIS.

FIG.104 (CON'T)

FIG. 105



FIG. 106



FIG. 107



FIG. 108




201
203
103
117
100
812
1068
1070
1072
170
112
120
128
184
109
108
1052
113
111
119

FIG. 109

FIG. 110



FIG. 111



FIG. 112


START
1079
1080
RECEIVE A BALE ON A BALE RECEIVING PORTION OF A LOAD BED ALONG RECEIVING AXIS
1081
READY TO DISCHARGE THE BALE(S) FROM THE LOAD BED TO A GROUND SURFACE ?
NO
YES
1087
HAS THE LAST BALE RECEIVED REACHED A PREDETERMINED POSITION ON THE BALE RECEIVING PORTION OF THE LOAD BED INDICATING THAT THE BALE IS FULLY FORMED ?
NO
YES
1088
TRANSFER THE BALE(S) ACROSS THE LOAD BED TO ACCUMULATING THE BALES ON BALE ACCUMULATING PORTIONS OF THE LOAD BED ADJACENT TO THE BALE RECEIVING PORTION OF THE LOAD BED
1083
YES
1082
HAS THE LAST BALE RECEIVED REACHED A PREDETERMINED POSITION ON THE BALE RECEIVING PORTION ON THE LOAD BED INDICATING THAT THE BALE IS FULLY FORMED ?
NO
DECOUPLE THE BALE RECEIVING PORTION OF THE LOAD BED FROM THE BALE ACCUMULATING PORTIONS OF THE LOAD BED
1089
YES
1086
DESIRE TO DISCHARGE THE BALE(S) FROM ONLY THE BALE RECEIVING PORTION ?
NO
YES
1084
DESIRE TO DISCHARGE THE BALE(S) ON THE BALE RECEIVING PORTION OF THE LOAD BED AND THE BALE(S) ON THE BALE ACCUMULATING PORTION OF THE LOAD BED AT THE SAME TIME ?
NO
YES
1090
DISCHARGE THE BALE(S) ONLY ON THE BALE ACCUMULATING PORTIONS OF THE LOAD BED TO THE GROUND SURFACE
1085
COUPLE THE BALE RECEIVING PORTION OF THE LOAD BED TO THE BALE ACCUMULATING PORTIONS OF THE LOAD BED
1091
DISCHARGE THE BALE(S) ONLY ON THE BALE RECEIVING PORTION OF THE LOAD BED TO THE GROUND SURFACE
SELECTIVELY DISCHARGE THE BALES ACCUMULATED ON THE LOAD BED
1092
DISCHARGE THE BALE(S) ON THE BALE RECEIVING PORTION OF THE LOAD BED AND THE BALE(S) ON THE BALE ACCUMULATING PORTIONS OF THE LOAD BED TO THE GROUND SURFACE AT THE SAME TIME

FIG. 116

TOP VIEW



FIG. 113



100

FIG. 117

REAR VIEW





FIG. 114

100



FIG. 118

REAR VIEW

100



FIG. 115

100



FIG. 119

REAR VIEW




1096
START
1095
1097
RECEIVE A BALE ON AN AGRICULTURAL BALE ACCUMULATOR
1098
HAS THE BALE REACHED A PREDETERMINED POSITION ON THE ACCUMULATOR INDICATING THAT THE BALES ARE FULLY FORMED ?
NO
YES
1099
FORM A STACK OF BALES ON THE ACCUMULATOR.
1101
TRANSFER THE STACK OF BALES ACROSS THE ACCUMULATOR TO ACCUMULATE THE STACKS OF BALES ON THE ACCUMULATOR.
1100
READY TO DISCHARGE THE STACKS OF BALES RECEIVED AND ACCUMULATED ON THE ACCUMULATOR TO A GROUND SURFACE?
NO
1102
YES
DETERMINE A RATE OF SPEED THAT THE ACCUMULATOR IS TRAVELING IN A FORWARD DIRECTION ACROSS THE GROUND SURFACE.
DETERMINE THE STACKS OF BALES FROM THE ACCUMULATOR TO THE GROUND SURFACE IN A DIRECTION OPPOSITE TO THE FORWARD TRAVELING DIRECTION OF THE ACCUMULATOR RESPONSIVE TO THE DETERMINED FORWARD RATE OF SPEED OF THE ACCUMULATOR.
1103

FIG.120

FIG. 121

100



FIG. 122

100



FIG. 123

100



FIG. 124

100



1115

FIG. 125


1116
START
1117
DETERMINE A LOCATION OF AN AGRICULTURAL BALE ACCUMULATOR IN A FIELD.
1118
OPERATE ACCUMULATION AND/OR DISCHARGE AN AGRICULTURAL BALE ACCUMULATOR RESPONSIVE TO THE DETERMINED LOCATION OF THE AGRICULTURAL BALE ACCUMULATOR IN THE FIELD.

FIG. 126


1119 START
1129 RECEIVE AND ACCUMULATE A PLURALITY OF BALES ON AN AGRICULTURED BALE ACCUMULATOR
1124 DETERMINE A FRESINT" NUMBER OF BALES FULLY FORMED,RECEIVED AND ACCUMULATED ON THE ACCUMULATOR
1122 DETERMINE PAST DISTANCE TRAVELED BY THE ACCUMULATOR IN THE FIELD
1123 DETERMINE AN AVERAGE NUMBER OF BALES RECEIVED AND ACCUMULATED ON THE ACCUMULATOR OVER THE PAST DISTANCE TRAVELED BY THE ACCUMULATOR
1124 HAS THE ACCUMULATOR REACHED ITS MAXIMUM BALE ACCUMULATING CAPACITY ?
YES
NO
1125 IS THE ACCUMULATOR LOCATED IN A PREDETERMINED BALE DISCHARGE ZONE IN THE FIELD ?
YES
NO
1133 IS THE ACCUMULATOR LOCATED IN A PREDETERMINED BALE DISCHARGE ZONE IN THE FIELD ?
YES
NO
1134 DISCHARGE ALL THE ACCUMULATED BALES ON THE ACCUMULATOR TO A GROUND SURFACE IN THE PREDETERMINED BALE DISCHARGE ZONE
1132 DISCHARGE THE DETERMINED PRESENT NUMBER OF BALES ACCUMULATED ON THE ACCUMULATOR FROM THE ACCUMULATOR TO A GROUND SURFACE IN THE PRESENT BALE DISCHARGE ZONE
1126
1127 SUBTRACT THE PRESENT NUMBER OF BALES ACCUMULATED ON THE ACCUMULATOR FROM THE ACCUMULATORS MAXIMUM BALE ACCUMULATING CAPACITY TO DETERMINE THE REMAINING NUMBER OF BALES THAT THE ACCUMULATOR CAN ACCUMULATE BEFORE THE ACCUMULATOR REACHES ITS MAXIMUM BALE ACCUMULATING CAPACITY
1128 DETERMINE A REMAINING DISTANCE BETWEEN THE ACCUMULATOR'S PRESENT LOCATION AND THE NEXT PREDETERMINED BALE DISCHARGE ZONE
1134 IS THE DETERMINED FUTURE NUMBER OF BALES TO BE ACCUMULATED BEFORE THE NEXT BALE DISCHARGE ZONE GREATER THAN THE DETERMINED REMAINING NUMBER OF BALES THAT THE ACCUMULATOR CAN ACCUMULATE BEFORE THE ACCUMULATOR REACHES IS MAXIMUM BALE ACCUMULATING CAPACITY ?
YES
NO
1129 MULTIPLY THE AVERAGE NUMBER OF BALES ACCUMULATED OVER THE PAST DISTANCE TRAVELED BY THE ACCUMULATOR BE THE DETERMINED REMAINING THE DISTANCE BETWEEN THE ACCUMULATOR'S PRESENT LOCATION AND THE NEXT PREDETERMINED BALE DISCHARGE ZONE TO DETERMINE A FUTURE NUMBER OF BALES FOR THE ACCUMULATOR TO ACCUMULATE BEFORE THE ACCUMULATOR REACHES THE NEXT BALE DISCHARGE ZONE
1170
1171 DETERMINE A REMAINING DISTANCE BETWEEN THE ACCUMULATOR'S PRESENT LOCATION IN THE FIELD AND THE NEXT BALE DISCHARGE ZONE IN THE FIELD
1172 ESTIMATE A FUTURE NUMBER OF BALES TO BE RECEIVED AND ACCUMULATED OVER THE REMAINING DISTANCE BETWEEN THE ACCUMULATOR'S PRESENT LOCATION AND THE NEXT BALE DISCHARGE ZONE
1173 DISCHARGE THE ESTIMATED FUTURE NUMBER OF BALES FROM THE ACCUMULATOR TO A GROUND SURFACE AS THE ACCUMULATOR TRAVELS THE REMAINING DISTANCES

FIG. 127


1184
1180
1136
1137
1142
1137
1144
1146
START
1148
1138
END
1150
1184
1136
1140
1182


1154
1155
USER INTERFACE MODULE
1156
KEYPAD
1157
DISPLAY
1158
COMPACT DISK OR FLOPPY DISK DRIVE
1159
VISUAL INDICATORS (LIGHTS)
1160
AUDIBLE INDICATOR (SPEAKER)
1161
COMPUTER INTERFACE (DIRECT LINE OR RADIO FREQUENCY)
1162
INTER NET OR INTRA NET INTERFACE
1163
BALER INTERFACE MODULE
1164
TRACTOR INTERFACE MODULE
1165
REAL TIME CLOCK MODULE
112
BASE MODULE
SENSOR(S)
186
BALE TRANSFER MODULE
SENSOR(S)
1190
BALE DISCHARGE MODULE
SENSOR(S)
CONTROLLER (WITH A MEMORY UNIT)
LOAD BED EXTENSION MODULE
SENSOR(S)
102
BALE STACKING MODULE
SENSOR(S)
332
BALE ARRANGEMENT CONTROL MODULE
SENSOR(S)
830
BALE STABIL-IZATION MODULE
SENSOR(S)
899
PERMISSIVE BALE DISCHARGE MODULE
SENSOR(S)
1052
SELECTIVE BALE DISCHARGE CONTROL MODULE
SENSOR(S)
1093
BALE SPEED DISCHARGE CONTROL MODULE
SENSOR(S)
1106
BALE ADVANCE-MENT MODULE
SENSOR(S)
798
FIELD LOCATION CONTROL MODULE
SENSOR(S)
1115

FIG. 128

FIG. 129


203
202
998
899
105
164
130
104
140
102
206
372
1168
332
336
364
1168
830
115
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
125
180
176
122
172
1106
186
184
174
123
178
127
182
107
146
166
120
112
116
908
134
114
118
106
128
132

FIG. 130


203
201
364
332
1168
1168
372
1052
998
1094
103
109
184
170
999
168
186
117
150
914
119
111
105
102
910
912
206
140
208
1106
140
206
798
108
120
128
112


148
140
202
164
105
180
125
102
150
206
124
176
104
137
1093
208
1094
172
122
136
117
372
186
116
119
336
798
170
160
103
120
168
184
1106
174
166
123
118
138
126
178
106
182
127
139
146
107
201

FIG. 131
100


103
914
208
112
206
912
798
150
208
140
332
117
372
1094
186
140
190
108
128
146
910
105
102
998
168
999
170
119
1168
184
1106
203
201

FIG. 132

100